

Widget Reboot / Power




Use **Reboot** to restart your LoxBerry. This may take a while - the appearing progress bar is shown until your LoxBerry is available again.

Use **Shutdown** to shut down your LoxBerry. To re-enable it, an original Raspberry needs to be plugged off and on.

On the top, you may get informed about changes that require a restart of your LoxBerry. LoxBerry itself never triggers an automatic restart, with the exception of important Linux security updates that require a reboot. If a LoxBerry task, like LoxBerry Update, or a plugin installation, is running in the background, you may be prevented to reboot or shutdown. Please wait until the installation has finished.

Further information

If LoxBerry or a plugin requests a reboot, this is shown on top of the page:



A reboot request is also always shown in the footer bar with a red exclamation mark.



A reboot request is part of LoxBerry's [Healthcheck](#). If a reboot is pending, this is reported as an error, as a LoxBerry Update, an automatic plugin installation or update, or a changed system setting needs a reboot to apply.

From:

<https://wiki.loxberry.de/> - **LoxBerry Wiki - BEYOND THE LIMITS**

Permanent link:

https://wiki.loxberry.de/konfiguration/widget_help/widget_reboot_power

Last update: **2022/09/10 12:18**